

Module Painting Instructions

AMRS MODULE PAINTING INSTRUCTIONS 7-1-17

1. Before painting, seal all wood except top with Zinsser Shellac thinned with denatured alcohol – one part shellac to one part denatured alcohol. This can be easily and quickly brushed on in a well ventilated area. It should be dry for sanding within 15 minutes. We do not recommend sealing and painting the top surface of the module at least until after you have glued your roadbed and any other object that you plan to glue to the deck.

- Sanding Sealer: Zinsser Shellac - one part shellac to one part denatured alcohol
- Also available pre-thinned and in 12-oz. spray can

2. Paint front and rear long sides, legs, leg bracing and all inside surfaces. **Seal, but DO NOT paint the outside surfaces of the ends where the modules meet.** We recommend removing the legs for painting.

- Module front and rear fascia exterior: (2) coats Sherwin-Williams SuperPaint Interior Acrylic Latex 2851 Sage Green Light SATIN finish
- Legs and bracing: (2) coats Sherwin-Williams SuperPaint Interior Acrylic Latex 6994 Greenblack SATIN finish
- All interior/underneath surfaces: white (spray can or any white acrylic paint)

3. After the paint has dried, seal the surfaces where legs, braces, and the interior sides of the modules come together with paste wax to keep the surfaces from sticking together when the legs are folded.

- Minwax Paste Finishing Wax or equivalent